




Drawer instructions



Drawer Side to Side Adjustment
Side adjustment +/- 1.5mm


Drawer Up and Down Adjustment
Height adjustment +/- 2mm using the thumbwheel

Drawer Front Release Button




Drawer Front Release Button


Drawer Up and Down Adjustment
Height adjustment +/- 2mm using the thumbwheel - no tools required



Drilling positions for drawer fronts



Drawer instructions - Assembly/Disassembly



Cover Plate



Drawer front assembly and disassembly

Assembly

The drawer front are slipped into place and clipped on with slight downward pressure



Disassembly

Two blue push button either side of the drawer to unlock the drawer front, with slight upward pressure and firmly holding while the drawer is released

DIY

KITCHENS

Drawer instructions

Fitting the Drawers


The drawer is fitted simply by placing it in on the runners and simply slide the drawer in carefully. Two catches lock on automatically to attach it on the runner also preventing the drawer from being inadvertently pulled all the way out.




Removing the Drawers

To Remove press the 2 Drawer Box Release clips located under the drawer box either side. Pull the drawer box out gently holding the drawer box firmly

Pan Drawer instructions




Drilling positions for pan drawer fronts





Pan Drawers

As a Normal drawer box but rails are fitted either side to the back rail of the drawer box and the drawer front



Grey sleeve to cover white drawer front fixing clip



Fixing to the back rail of the drawer box



Fixing to the Drawer Fronts

