NETGEAR BUSINESS

Installation Guide

NETGEAR 5-Port and 8-Port Gigabit Ethernet Smart Managed Plus SOHO Switch Model GS305E and GS308E



Package Contents

- Switch model GS305E or GS308E
- Power adapter (varies by region)
- Installation guide

Ethernet cables not included.

1. Register with the NETGEAR Insight App

Use the NETGEAR Insight app to register your switch, activate your warranty, and access support.

1. On your iOS or Android mobile device, visit the app store, search for NETGEAR Insight, and download the latest version of the app.



- 2. Open the NETGEAR Insight app.
- 3. If you did not set up a NETGEAR account, tap Create NETGEAR Account and follow the onscreen instructions.
- 4. Enter the email address and password for your account and tap LOG IN.
- 5. Tap + in the upper-right corner.
- 6. Either use the camera on your phone to scan the serial number bar code located on the bottom of the switch, or enter the serial number.
- 7. Tap **Go**.
- 8. Follow the onscreen instructions to add your switch to a network location. The switch is registered and added to your account.
- 2. Connect the Switch

Sample Network Configuration



An IP address is required to configure your switch. The switch gets an IP address from a DHCP server (such as your router) by default. If your switch is not connected to a DHCP server, use the default IP address: 192.168.0.239.

- 4. Log in to your account.

the switch.

- network as your switch.
- 3. Enter the password.
- 4. Click the **Login** button.

3. Discover the IP Address of the Switch

1. Connect your mobile device to the same WiFi network as the switch.

2. Make sure that the network connects to the Internet.

3. Launch the NETGEAR Insight app from your mobile device.

The current IP address of the switch displays.

4. Configure the Switch

We recommend that you use a web browser on a computer or tablet to configure

Note: If your computer is a Mac, use the NETGEAR Switch Discovery Tool, as described on the other side of this document.

1. Open a web browser from a computer or tablet connected to the same

You can use a WiFi or wired connection.

2. Enter the IP address of the switch.

The default password is **password**. We recommend that you change the password to a more secure password.

Other Discovery and Configuration Methods

The NETGEAR Switch Discovery Tool and the ProSAFE Plus Utility also let you discover the IP address and configure the switch.

- **NETGEAR Switch Discovery Tool**. You can use a Mac or a 64-bit Windowsbased computer that is on the same network as the switch. You can use a WiFi or wired connection. When you discover the switch, this tool provides access to the local browser interface to configure the switch. To download the NETGEAR Switch Discovery Tool, visit www.netgear.com/support/product/netgear-switch-discovery-tool.aspx.
- ProSAFE Plus Utility. To download the latest utility and user manual, visit www.netgear.com/support/product/PCU.

If you cannot discover or configure the switch, you might need to temporarily disable the firewall, Internet security, or antivirus programs. Make sure to reenable these security services after you discover and configure the switch.



Thank you for purchasing this NETGEAR product. You can visit https://www.netgear.com/support/ to register your product, get help, access the latest downloads and user manuals, and join our community. We recommend that you use only official NETGEAR support resources.

Si ce produit est vendu au Canada, vous pouvez accéder à ce document en français canadien à https://www.netgear.com/support/download/. (If this product is sold in Canada, you can access this document in Canadian French at https://www.netgear.com/support/download/.)

See the regulatory compliance document before connecting the power supply.

warranty information.



For regulatory compliance information including the EU Declaration of Conformity, visit https://www.netgear.com/about/regulatory/.

Do not use this device outdoors. If you connect cables or devices that are outdoors to this device, see https://kb.netgear.com/000057103 for safety and