



PS-1206UWg



USB EZmax VISTA MAC

Supports Wired or Wireless Network

The print server supports 10/100Mbps Wired and IEEE 802.11b/g wireless network. Users can share the printer and configure the print server either through a wired or wireless network.

Easy Installation and Configuration (with Web-Based Configuration)

The print server's easy-to-use Windows installation wizard enables a guick installation and setup of the print server. The print server can also be conveniently configured from any network client that supports web-browsing.

Supports Peer-to-Peer and Server-Based Printing

Supports both Peer-to-Peer and Server-based printing. LAN clients can connect directly with the print server to execute printing jobs (Peer-to-Peer printing); or clients can send print jobs first to a server (queuing jobs) and allow the server to connect with the print server to execute the printing jobs (Server-based printing).

Provides Complete Printing Methods

The print server provides LPR, IPP, SMB/TCP, Raw Printing and Unix Logical Printer printing methods. You can choose the best printing method according to your environment.

Fault-Tolerant Firmware Upgrades

Users don't need to worry about errors occuring in the midst of an upgrade, thus preventing the print server from operating. The print server's fault-tolerant upgrade function allows for re-upgrades, should problems occur during the initial upgrade.

Supports 64/128-bit WEP, WPA encryption protects wireless communication

This print server supports 64/128-bit WEP data encryption to protect your wireless network from eavesdropping. It also supports WPA robust encryption to prevent your network intruded.

Includes user friendly EZmax setup wizard and utility

PS-1206UWg provides user friendly EZmax setup wizard with ease installation steps and wireless connection utility to facilitate wireless connectivity.









FEATURES AND TECHNICAL SPECIFICATIONS

- Complies with wireless 802.11b/g standards
- Includes multi-language EZmax setup wizard
- Shares USB printer* within the network users
- Supports TCP/IP, IPX/SPX, NetBEUI and Apple Talk protocols
- Supports LPR, IPP, SMB/TCP and RAW printing protocols

HARDWARE INTERFACE	STANDARD	SECURITY
	 IEEE802.3, IEEE802.3u IEEE802.11b, IEEE802.11g 	WEP 64/128, WPA

CPU	POWER ADAPTER	LED
NISC CPU	● 5V / 1A	WLANSTATUSLAN
Flash / RAM	DIMENSION	HUMIDITY & TEMPERATURE
₱ 1MB NOR Flash₱ 8MB SDRAM	♦ 22(H) x 62(W) x 82(D) mm	 # 10~90% (Non Condensing) # 0~55°C
SYSTEM REQUIREMENTS	OUTPUT POWER	CERTIFICATIONS
 Windows 2000/XP/Vista Mac 10 4 x and above 	● 16dBm - 18dBm	CE, FCC

Mac 10.4.x and above

NETWORK SETUP DIAGRAM AND RELATED PRODUCTS

An example of how the **PS-1206UWg** can be setup:

- Connect the PS-1206UWg print server to your computer.
- Setup the print server connection by running the multi-language EZmax setup wizard.
- Connect to printer* within the network users.

